



# Assembly Instructions For Drying Screen Unit

Each drying screen unit consists of:

- 5 screens
- 2 black unit sides
- 4 stainless steel connecting tubes
- 8 screws
- 1 hexagonal socket wrench

Place a screw in a hole of one of the unit sides and screw into the end of a connecting tube, so the connecting tube is on the same surface as the screen guide slots. Tighten the screw. Place another screw in a hole of the other unit side, so when screwed into the other end of the first connecting tube, the screen guide slots face each other and run in the same direction. Tighten the second screw. Install the remaining 3 connecting tubes in the same manner. The screens may now be slid into the guide slots. The RH Drying Screen Unit is now ready for use. The screens may be used either way up: screen surface level with the top edge of the frame or surrounded by the frame.

Should the screen surface become damaged at any stage it may be replaced locally by a competent person or returned to RH Conservation Engineering.

Please Note: RH equipment is intended for use only by professional conservators. Use by inexperienced operators may result in damage to objects being treated. The RH Drying Screen Unit is not intended for use by infirm persons and should be kept out of reach of young children.